

Installing Your Device to the Cell Pal Holster



Your device or it's holster must have a "J" style hook on the back. This keeps the holster from falling down your leg while wearing it, and pulls the holster up when drawing it.



You're going to separate the two pieces of leather



Stick the tea spoon handle between the holster and the front tab of leather and twist it like a key. This will help separate the two new pieces of leather and spread the opening to make it easier to slip your device in.



Slip your device holster clip in between the two pieces of leather.



Make sure you push it all the way through. Push the device holster up and down working the "J" hook onto the front piece of leather.

© 2008 - Keith Morrison – Authorized Distributor of Cell Pal Holsters –
www.ConcealedComfort.com

The Ultimate in Concealed Carry - Never Leave Your Gun Behind Again!